



5




6




BAFLO

BA11


- (D) Montageanleitung
- (GB) Assembly instructions
- (ES) Instrucciones de instalación
- (FR) Instructions de montage
- (CZ) Montážní návod
- (PL) Instrukcja montażu
- (HU) Összeszerelési útmutató
- (SK) Montážny návod
- (RU) Инструкции по монтажу
- (IT) Istruzioni di montaggio
- (RO) Instrucțiuni de asamblare
- (TR) Montaj talimatı
- (NL) Handleiding voor de montage



99,5/34,5/101,5



Lp.	A	Lp.	A
8	966x412		
7	966x412		
6	974x78		
5	956x304		
4	956x304		
3	318x974	11	973x317
2	318x974	10	973x352
1	993x345	9	973x322



4x 4x24 A4	12x 3x20 A2	10x G1	8x 8x30 K1	24x Z5	10x B3	12x B5	2x H1
12x 3,5x16 A3	2x U1	4x W2	4x Z3	2x B2	26x 20,5 M1	26x T1	4x 4x30 A1
							1x Z1

