

IMPORTANT & WARNINGS:

- Remove all parts from packaging carefully.
- This is a heavy unit!! When assembling and unassembling we recommend that 2 or more adults are involved.
- Keep children & Pets away when assembling or unassembling.
- Do not climb on the frame
- This product is not a toy and should NOT be used as a swing under any circumstances as this could result in injury.
- Max recommended weight is 120Kgs
- This product is only designed to seat 1 person at any given time. DO NOT exceed this as this could damage the product and cause injury; and void your warranty.
- Keep all flame and heat sources well away from this product at all times.
- Take care not to trap fingers whilst assembling and unassembling.
- When not in use please store away in a cool and dry place away from any heat source.

Assembly Instructions

A		1PC
B		1PC
C		1PC
D		1PC
E		1PC
F		2 PCS
G		4 PCS
H		2 PCS
I		1PC
J		1PC

