






ANGEL

AK 165




12.3.2018

- D** Montageanleitung
- FR** Notice de montage
- NL** Handleiding voor de montage
- CZ** Montážní návod
- HU** Szerelési útmutató
- TR** Montaj talimatı
- GB** Assembly Instructions
- IT** Istruzioni di montaggio
- PL** Instrukcja montażu
- SK** Návod na montáž
- RO** Instrucțiunile de montaj
- RU** Инструкции по монтажу





20 min.





1




ZC X12 8x52	X X18 ppw	C X16 ND 3.5x16	Z X16 SLZ	N X1 3x20	TB X1	TA X1 GLUE	V X18 3x13	Z X12 PB 1/2
A X48	PPW X6	ND X25	SLZ X8	RC X24 3x20	RC X4	H X12 6.3x13	RC X4 1/2	B X2 X16





2










7







8




9




10








15

- C  x8
- Z  x8







16

- C  x8
- Z  x8










17

- C  x8
- Z  x8




18

- ZC  x12
- N  3x20 x12
- X  x18
- SIZ  x8





19






Z


x12



ND




20



TB

x1



TA

x1



ND

x1



V

x18

3x13