









# COMPONENTS LIST

Also available from  
**tech+link**  
 International


tech+link  
**SUPPORT**



ADDITIONAL CONTENTS THAT MAKE UP THE  
 PRECONSTRUCTED FRONT PLATE ASSEMBLY




tech+link, a division of Tapehand Ltd.  
 Unit 8, Bat & Ball Enterprise Centre,  
 Bat & Ball Road, Sevenoaks, Kent.  
[www.techlink.uk.com](http://www.techlink.uk.com)



**TLCD5**  
 LCD WALL MOUNT


**ASSEMBLY  
 INSTRUCTIONS**

### STAGE 1




Drill six holes in the wall using the Back Plate **A** outer holes as a pattern. Insert the Rawl Plugs **E** before mounting the Back Plate **A** to the wall using the Wall Screws **F**

### STAGE 2




Mount the Front Plate **B** on to the LCD screen using the M4 Screws **C** or M5 Screws **D**.

### STAGE 3



Insert the LCD screen and Front Plate assembly **B** into the keyhole slots on the Back Plate **A** and gently lower until securely in place.

### TILT METHOD



A choice of two screen angle positions (upright or 5° tilt) is available. Choose the appropriate locating notch as the screen and Front Plate assembly is lowered into the Back Plate.

### TILT METHOD

