







Montageanleitung

Service-Hotline
01805-678101
0,14€ pro Min.

++49 für Österreich
Auslandstarif pro Min.
service@optifit.de
voor Nederland en België
00800-40119350
benelux@optifit.de



T 606-9 / T 606-6
T 606APL-9 / T 606APL-6
TL 606APL-9



Ersatzteile/Spare parts/pièces de rechange/Reserveonderdelen/Piezas de recambio/Ricambi/Запасные части/Części zamiennel/pótalkatrészek/Náhradní části/Nadomestni deli/varaosat/reservdelar

T 606-9	(H) E940611	(L) E946048	
T 606-6	(H) E980611	(L) E946048	
T 606APL-9	(H) E940611	(L) E946048	(P) E540103
T 606APL-6	(H) E980611	(L) E946048	(P) E441103
TL 606APL-9	(H) E940621	(L) E946048	(P) E540103 (Z) E947100