





















Service-Hotline
01805-678101
0,14€ pro Minute
++49 für Österreich
Auslandstarif pro Minute
service@optifit.de
voor Nederland en België
00800-40119350
benelux@optifit.de



Montageanleitung



Ersatzteile/ Spare parts/pièces de rechange/ Reserveonderdelen/Piezas de recambio/Ricambi/Запасные части/Części zamienne/pótalkatrészek/Náhradní části/Nadomestni deli/varaosat/reservdelar


U 536-9	A	E961021	B	E961022	C	E951224	F	E970974	G	E970117	J	E940563	J1	E940592	J2	E940644	L	E970974	P	E540104	S	E946149	S1	E946148
UO 536-9	A	E961021	B	E961022	C	E951224	F	E970974	G	E970117	J	E940563	J1	E940592	J2	E940644	L	E970974	S	E946149	S1	E946148		

Montageanleitung

1cm2cm3cm4cm5cm









1

→

2

→

3

...

6x



Nr.518

1x



LEIM

Nr.128

12x



4x25

Nr.334

6x



M4x36

Nr.460

18x



3x13

Nr.155

8x



4x15

Nr.336

6

3

4

8

10

124

496

J

SK

Schubkasten

316

496

J2

AZ

Auszug

252

496

J1

AZ

Auszug

V

V

Service-Hotline
01805-678101
0,14€ pro Minute
+ +49 für Österreich
Auslandstarif pro Minute
service@optifit.de
voor Nederland en België
00800-40119350
benelux@optifit.de


1

Holzunterlage verwenden!
Use a wooden base!
Utiliser un support en bois!
Houten onderlegger gebruiken!
Utilizar bases de madera!
Utilizzare una base di legno!
Применять деревянную подложку!
Używać podkładkę z drewna!
Alkalmazzon fa alátételt!
Použíte dřevěný podklad!
Uporabite leseno podlago!
Käytä puualustaa!
Använd ett träunderlag!

J1

J2


Ø5



2

U

Ø4



3

Schubkasten-
blende

518

J

124


518

Auszugs-
blenden

J1

J2

252/316




4

128

Q

Q1

128



5

Q


U

R

Q1

U1

10 min.



6

SK

Schubkasten


J

U

Q

334

Q1



AZ

Auszug


J1

J2

Q1

334

U



7

SK

Schubkasten


124

J

R

Q1

Ø5




8

J

J1

J2

460



9

155

T

Q


R

Q1

T1

155

U1



10

V

U

R

336


J1

J2

U1

AZ

Auszug



Ersatzteile/Spare parts/pièces de rechange/Reserveonderdelen/Piezas de recambio/Ricambi/Зачпасные части/Części zamienne/рѳталкартсзек/Náhradní části/Nadomestni deli/Varaosat/reservdelar	
SK	⓪ E945400 Ⓢ E970151 Ⓣ E946151 Ⓣ E946150 Ⓢ E945407 Ⓢ E945407
AZ	⓪ E945400 Ⓢ E945400 Ⓢ E970151 Ⓣ E946151 Ⓣ E946150 Ⓢ E945407 Ⓢ E446157
AZ	Ⓢ E945400 Ⓢ E945400 Ⓢ E970151 Ⓣ E946151 Ⓣ E946150 Ⓢ E945407 Ⓢ E446157

500653.2C 06/08 sl