

















Montageanleitung

Service-Hotline
01805-678101
0,14€ pro Minute
++49 für Österreich
Auslandstarif pro Minute
service@optifit.de
voor Nederland en België
00800-40119350
benelux@optifit.de



Ersatzteile/Spare parts/pièces de rechange/Reserveonderdelen/Piezas de recambio/Ricambi/Запасные части/Części zamienn/pótalkatrészek/Náhradní části/Nadomestni deli/varaosat/reservdelar

80cm O806-6	(A) E940036	(B) E940036	(C) E941232	(D) E940332	(E) E940100	(G) E971009	(H) E980613
100cm O100-6/O106-6	(A) E940036	(B) E940036	(C) E942231	(D) E941331	(E) E940100	(G) E971026	(H) E980612
100cm OG156-6	(A) E940036	(B) E940036	(C) E942231	(D) E941331	(E) E940100	(G) E971026	(H) E940647
100cm OG106-9	(A) E940036	(B) E940036	(C) E942231	(D) E941331	(E) E940100	(G) E971026	(H) E940647