





Montageanleitung









1 → 2 → 3 ...



Service-Hotline
01805-678101
0,14€ pro Minute
++49 für Österreich
Auslandstarif pro Minute
service@optifit.de
voor Nederland en België
00800-40119350
benelux@optifit.de

80cm SPLO801-6
100cm SPLO101-6
100cm SPLO100-6



Ersatzteile/Spare parts/pièces de rechange/Reserveonderdelen/Piezas de recambio/Ricambi/Запасные части/Części zamienn/pótalkatrészek/Náhradní části/Nadomestni deli/varaosat/reservdelar

SPL800-6	(A) E962025	(B) E962026	(C) E962222	(G) E445118	(H) E980623	(L) E970972	(P) E448270	(Z) E446480
SPL100-6	(A) E962025	(B) E962026	(C) E962221	(G) E445116	(H) E980622	(L) E970971	(P) E446450	(Z) E446480
SPLO100-6	(A) E962025	(B) E962026	(C) E962221	(G) E445116	(H) E980622	(L) E970971		