













Service-Hotline
01805-678101
0,14€ pro Min.
++49 für Österreich
Auslandstarif pro Min.
service@optifit.de
voor Nederland en België
00800-40119350
benelux@optifit.de

Montageanleitung



H 506-6



50cm H506-6 (A) E961011 (B) E961012 (C) E954224 (C1) E954224 (C2) E950224 (D) E950304 (G) E970021 (H) E980601 (L) E970974

500584.1B 01/10 sl