














- D** Montageanleitung
- NL** Handleiding voor de montage
- TR** Montaj talimatı
- FR** Instructions de montage
- CZ** Montážní návod
- HU** Összeszerelési útmutató
- GB** Assembly instructions
- PL** Instrukcja montażu
- RU** Инструкция по монтажу
- IT** Istruzioni di montaggio
- RO** Instructiuni de asamblare
- SK** Montážny návod






A	B	C (mm)		D
1	M143-004	1897	484	2/2
2	M143-105	1972	371	2/2
3	M143-106	1972	371	2/2
4	M143-202	660	400	1/2
5	M143-306	572	351	1/2
6	M143-307	572	351	1/2
7	M143-308	572	351	1/2
8	M143-309	571	351	1/2
9	M143-5502	1972	80	2/2
10	M143-5503	1972	58	2/2
11	M143-5505	1972	80	2/2
12	M143-9902	1899	583	2/2







2 




3









6



7



8

**Pflegehinweis!**

Bitte nur mit einem Staubtuch
(kein Microfasertuch) oder
einem feuchten Lappen reinigen.
KEINE scheuernden Putzmittel
verwenden!

Wskazówka dotycząca pielęgnacji!

Proszę czyścić tylko suchą lub lekko
wilgotną szmatką do kurzu. Nie używać
żadnych środków szorstkich!

