
















- (D)** Montageanleitung
- (NL)** Handleiding voor de montage
- (TR)** Montaj talimatı
- (FR)** Instructions de montage
- (CZ)** Montážní návod
- (HU)** Összeszerelési útmutató
- (GB)** Assembly instructions
- (PL)** Instrukcja montażu
- (RU)** Инструкция по монтажу
- (IT)** Istruzioni di montaggio
- (RO)** Instructiuni de asamblare
- (SK)** Montážny návod








A	B	C (mm)		D
1	S182-008	496	180	2/2
2	S182-010	716	496	2/2
3	S182-011	716	496	2/2
4	S182-012	496	180	2/2
5	S182-013	496	180	2/2
6	S182-116	874	415	1/2
7	S182-117	874	415	1/2
8	S182-118	874	430	1/2
9	S182-119	874	430	1/2
10	S182-209	1500	430	1/2
11	S182-210	1500	430	1/2
12	S182-311	485	400	1/2
13	S182-313	475	400	1/2
14	S182-506	428	100	1/2
15	S182-507	400	100	1/2
16	S182-508	400	100	1/2
17	S182-509	418	100	1/2
18	S182-909	886	501	2/2
19	S182-910	458	407	1/2
20	S182-911	448	407	1/2
21	S182-913	886	489	2/2



















6





7



1024WW20



Pflegehinweis!

Bitte nur mit einem Staubtuch (kein Microfasertuch) oder einem feuchten Lappen reinigen. KEINE scheuernden Putzmittel verwenden!

Wskazówka dotycząca pielęgnacji!

Proszę czyścić tylko suchą lub lekko wilgotną szmatką do kurzu. Nie używać żadnych środków szorstkich!

