













- D** Montageanleitung
- NL** Handleiding voor de montage
- TR** Montaj talimatı
- FR** Instructions de montage
- CZ** Montážní návod
- HU** Összeszerelési útmutató
- GB** Assembly instructions
- PL** Instrukcja montażu
- RU** Инструкция по монтажу
- IT** Istruzioni di montaggio
- RO** Instructiuni de asamblare
- SK** Montážny návod













A	B	C (mm)		D
1	S182-113	336	255	1/1
2	S182-114	336	255	1/1
3	S182-115	336	220	1/1
4	S182-208	1000	280	1/1
5	S182-310	475,5	220	1/1
6	S182-554	480	342	1/1
7	S182-908	977	346	1/1




1 §2





2 §6









5



6



**Pflegehinweis!**

Bitte nur mit einem Staubtuch
(kein Microfasertuch) oder
einem feuchten Lappen reinigen.
KEINE scheuernden Putzmittel
verwenden!

Wskazówka dotycząca pielęgnacji!

Proszę czyścić tylko suchą lub lekko
wilgotną szmatką do kurzu. Nie używać
żadnych środków szorstkich!

